


MASTER MP

Master-MP

Digital Readout System



REFERENCE MANUAL

ACU-RITE®



Master readout parameter access code

An access code must be entered before axis and system parameters can be set or changed. This prevents inadvertently resetting parameters.

IMPORTANT

The access code is 8891

Refer to Section 1. Master measuring system setup operations. Begin the parameter setup mode from the DRO mode by pressing the 2ND and SET SYS keys; a "Code _ _ _ _" message is displayed. Press the 8, 8, 9, and 1 keys. The "code" message is replaced with "Set sys", indicating that the Master readout is ready for parameter setting operations. Set parameters as described in Section 2.

IMPORTANT

Supervisors may wish to remove this page from the Master manual after initially setting up the readout system. Keep it in a safe place for future use.

Table of Contents

Section 1. INSTALLATION

<i>Introduction</i>	1-1
• <u>Accessories</u>	1-1
<i>Installing the Master measuring system</i>	1-2
• <u>Selecting Location</u>	1-2
• <u>Proper Mounting</u>	1-2
• <u>Connecting Encoders</u>	1-3
• <u>Connecting Accessories</u>	1-3
• <u>Connecting Ground, Checking Voltage, Connecting Power</u>	1-4
<i>Initial system power-up</i>	1-4

Section 2. System Set-up

<i>Set System Mode</i>	2-1
• <u>Setting Parameters</u>	2-1
• <i>Entering Set System Mode</i>	2-1
• <u>Quick Access Parameter Setting</u>	2-1
• <i>Entering Quick Access Mode</i>	2-1
• <u>Setting Axis Parameters</u>	2-2
• <i>Save Changes</i>	2-2
• <i>Abandon Changes</i>	2-2

KEY: Entering Numeric Information	2-2
-----------------------------------------	-----

Enc rES Encoder resolution	2-2
• <u>Choosing the Correct Resolution</u>	2-2
• <i>Table of Metric Encoder Settings</i>	2-2
• <i>Making a Numeric Entry for English Scales</i>	2-2
LEc Linear Error Compensation	2-3
• <u>Set LEC with a Numeric Entry</u>	2-3
• <u>Set LEC using Automatic Routine</u>	2-3
• <i>Manual Edgefinder, same side surfaces</i>	2-3
• <i>Manual Indicator, opposite side surfaces</i>	2-4
FRcEor Multiplier Factor	2-5
• <u>Setting Multiplier Factor</u>	2-5
nERr D Near Zero Warning	2-5
• <u>Quick Access Setup</u>	2-5
Enc dir Encoder Counting Direction	2-6
• <u>Setting Count Direction</u>	2-6
TooL dir Tool Offset Direction	2-6
• <u>Setting Tool Offset Direction</u>	2-6

Option Parameters	2-7
• Option Parameter Setting	2-7
SLEEP Sleep Mode Operation	2-7
• Setting	2-7

Section 3. Master-MP Readout Operations

DRO Operations	3-1
• Axis Display Settings	3-1
• Display Modes	3-1
• <i>Absolute and Incremental</i>	3-1
• <i>Distance to Go</i>	3-1
• Inch/Millimeter Measuring Units	3-1
• Display Resolution	3-2
• Zeroing Displays	3-2
• <i>Absolute</i>	3-2
• <i>Incremental</i>	3-2
• <i>Distance-to-Go</i>	3-2
DATUM Operations	3-2
• Setting Datum 0	3-2
• Multiple Datums	3-3
• Setting a Datum	3-3
• <i>Setting Datums from the Current Location</i>	3-3
• <i>Setting Datums from Print Dimensions</i>	3-3
• Selecting a Datum	3-3
Presetting Operations	3-4
• Entering Preset Mode	3-4
• Setting Absolute Presets Referencing the Current Datum	3-4
• Setting Incremental Preset from Current Position	3-4
• Presetting Options	3-5
• Midpoint Presetting	3-5
• <i>Finding a Midpoint</i>	3-5
• Tool Offsetting	3-5
• <i>Saving and Changing Tool Settings</i>	3-5
• <i>Selecting a Tool</i>	3-6
• <i>Turn Tool Offsetting Off</i>	3-6
• <i>Setting Tool Edge Indicator</i>	3-6
• Bolt Hole Patterns	3-6
• <i>Entering a Bolt Hole Pattern</i>	3-6
• <i>Running a Bolt Hole Pattern</i>	3-7
Programming Operations	3-7
• Entering or Exiting Programming Mode	3-7
• Entering a New Program	3-7
• <i>STEP 1: Entering an Absolute Preset</i>	3-8
• <i>STEP 2: Entering an Incremental Preset and Selecting a Tool</i>	3-8
• <i>STEP 3: Entering a Bolt Hole Pattern</i>	3-9
• <i>STEP 4: Setting an Absolute Preset from another Datum</i>	3-9

- **Running a Program** 3-10
- **Viewing or Editing a Program** 3-10
 - *Review/Edit an existing program*..... 3-10
 - *Inserting a program step* 3-10
 - *Deleting a program step* 3-11
 - *Creating multiple programs* 3-11
 - *Stopping the program at any point* 3-11
 - *Clearing the program memory* 3-11

Power Loss Restoration Features 3-11

- **Continu-Trac** 3-11
- **Recall** 3-11
- **Home Reference Point (HRP) Find Routine** 3-11
 - *Setting HRP* 3-12

Using an Electronic EdgeFinder Probe 3-12

- **Electronic Edgefinder Probe Tool Settings**..... 3-12
- **Zeroing at an Edge** 3-12
 - *Setting Workpiece 0 with an Edgefinder Probe* 3-12
 - *Setting Incremental Zero with an Edgefinder Probe* 3-13
- **Finding LEC using an Electronic Edgefinder Probe** 3-13

Section 4. Appendices

Appendix A. Troubleshooting 4-1

- **No Operation** 4-1
- **Internal Testing** 4-1
- **Resetting Factory Defaults** 4-2
- **Error Reports** 4-2

Appendix B. Master readout specifications 4-5

Appendix C. Encoder requirements 4-6

Appendix D. Accessory connectors and output specifications 4-7

- **Edgefinder** 4-7
- **Remote Zero** 4-7

Appendix E. Measurement displays 4-8

- **Display Increments with standard encoder resolution selections** 4-8

Appendix F. Warranty 4-9

- **FCC Compliance Statement** 4-9
- **The ACU-RITE Warranty** 4-9
- **30-day Red Carpet Warranty Service** 4-10

Installation

Introduction

The family of Master readouts are application-specific, full-featured readouts that provide the measuring features required to obtain the most productivity from your manual machine tool.

- Master-MP® is a two- or three-axis application-specific readout designed especially for milling operations. It includes features to support common milling requirements such as creating hole patterns, and can be programmed to assist with producing multiple parts.
- Master-TP® is a two- or three-axis application-specific readout designed especially for turning operations. It includes features to support common turning requirements such as tool offsets, and can also be programmed to assist with producing multiple parts.
- Master-G® is a one-, two-, or three-axis general-purpose readout that provides the features required for most common machine tool operations. Programming features are not provided.

All Master readouts can be provided with options to allow coupling of two encoders onto one measurement axis, provide bi-directional RS232-C serial communications with a computer or output to a printer, provide connections to a parallel printer, provide a Control Function Interface (CFI) for simple machine control functions, and to provide a battery backup.

• **Accessories**

Accessories are available to enhance your Master measuring system. They include:

- A Master Foot Switch for remote zeroing of selected axis displays
- An Edge Finder Probe to speed workpiece setup and measuring.

These accessories provide additional functions and capabilities to create a customized solution to your measuring system needs. To order these accessories, contact your ACU-RITE Distributor or Original Equipment Manufacturer/Importer (OEM/OEI), or call the ACU-RITE Sales and Service Center at (800) 344-2311.

Installing the Master Measuring System

IMPORTANT

Before installing the Master readout, record the serial number on the Warranty card. The serial number label is located on the bottom of the Master readout.

• Selecting Location

Selecting a location for the Master readout is an important consideration for proper installation. Keep the following points in mind when selecting a safe and convenient location:

- The Master readout should be within easy reach of the operator for access to the keypad and other controls.
- The Master readout should be at approximate eye level and tilted towards the operator.
- Avoid moving components or tools, and minimize coolant splash or spray.
- The operating environment must be within the range of 0° to 40° C (32° to 104°F), with a non-condensing relative humidity of 25% to 95%.



• Proper Mounting

ACU-RITE has developed special mounting kits for the Master readout which address the most common mounting requirements. Mounting kits include:

- Column and base machine mountings and floor stands
- Tray and yoke readout mounts
- Hardware and mounting instructions

These kits are available from your ACU-RITE Distributor, OEM/OEI, or the ACU-RITE Sales and Service Center at (800) 344-2311.

If fabricating a support device for the Master readout, it should be large and strong enough to accommodate the readout and any other devices that may be placed on top (printer, etc). It must also be stiff enough to minimize any vibration induced by machinery on the shop floor; vibration will make the displays difficult to read.




- **Connecting Encoders**

Encoder input receptacles :

INPUT 1	X Axis
INPUT 2	Y Axis
INPUT 3	Z Axis

Insert the male connector from each encoder, with the large spline down, into mating receptacle on the back of the Master readout. Lock it in place with a 1/4-turn of the outer shell. If using encoders other than ACU-RITE's, refer to the connector requirements in Appendix C of Section 4. Appendices. Obtain the correct connector and install it on the encoder cables.

Provide enough slack in the encoder cables to allow for full travel of all machine axes. Assure that cables will not be pinched by table movements. Use the cable tie-down hardware kits supplied with the encoders to fasten the cables neatly to the machine.



- **Connecting Accessories**

Connect all accessories to the Master readout. Refer to Appendix D in Section 4. Appendices for a description of the ACU-RITE Foot Switch and Edge Finder Probe accessories and hookup information.

Each accessory should be mounted so that:

- Vibration, normal material handling, traffic near the installation site, and operation of the machine will not damage the accessory or cause it to fall.
- Power and signal cords are out of the way so they will not be damaged by machining operations or normal traffic, and are not a tripping hazard to the operator.
- Cords provide enough length to allow normal movements of the machine tables, the Master readout and its mountings, and other machine or mounting components.
- The accessories are within the view and easy reach of the operator.

- **Connecting Ground, Checking Voltage, Connecting Power**


Connect a ground wire from the terminal on the back of the Master readout to the machine. The machine should also be connected to a solid earth ground.

Confirm the voltage available at the power source for connecting to the Master readout. Refer to Appendix B in Section 4. Appendices for a listing of the acceptable voltage ratings for use with the Master readout.



CAUTION

Connecting the Master readout to a power source outside of the acceptable range or making an inappropriate setting with the voltage selector may damage the Master readout or the encoders.


The voltage selector is set for 120VAC operation. If required, set the voltage selector to match the line voltage. Remove the caution label from the input module, and use a thin-bladed screwdriver in the slot at the top of the power input module to open the module cover. Pull the selection drum out, rotate it to the correct setting, and push it back into place. Close and snap the cover shut. The voltage setting will show through the window in the cover. Connect the Master readout to the power source using the power cord supplied.



Initial system power-up

Press the  key on the front of the Master readout. The X-axis display flashes "E1", indicating that power to the readout has been interrupted. Press the  key. The Master readout commences digital readout (DRO) mode operations, with all displays zeroed.

Proceed to Section 2. System Set-Up for instructions on entering setup parameters.



SYSTEM SET-UP

Set System Mode

Requires Access Code. Set when the readout is initially set-up and infrequently changed. Used to set all Axis Parameters.

- **Setting Parameters**

- **Entering Set System Mode:**

- Press SET SYS keys to start Setup
 - Enter Access Code # 8891, found at the front of this manual. (This page may have been removed for safekeeping.)
 - At display, Press axis key you wish to change. Ex:

The following parameters can be set for each axis:

<input type="text" value="E n c r e s"/>	Encoder Resolution
<input type="text" value="r A d - d i A"/>	Radius/Diameter Switching Enable
<input type="text" value="L E c"/>	Linear Error Compensation
<input type="text" value="E n c d i r"/>	Encoder Count Direction
<input type="text" value="F A c t o r"/>	Workpiece Scaling Factor Multiplier *
<input type="text" value="t o o L d i r"/>	Tool Offset Direction
<input type="text" value="n E A r 0"/>	Near-Zero Warning *

* Parameter may be set without entering code through Quick Access Setup

- **Quick Access Parameter Setting** - can be used for Scaling Factor Multiplier, Near-Zero Warning and CFI option. These parameters may be changed often during machining. Quick Access does not require access code entry and locks system parameters out to prevent accidental changes.

- **To Enter Quick Access Mode:** Press SET SYS and Axis Key. Ex:

• Setting Axis Parameters

- Press **ZERO** to display current parameter setting.
- Pressing **ZERO** repeatedly toggles through parameter choices.
- Pressing Axis key moves to the next parameter. Ex: **X**
- To set, or display, parameters on a new axis, Press desired axis key.
Ex: **Y** or **Z**

- **Save Changes:** Press **ON/OFF** to save settings and return to DRO mode.
- **Abandon Changes:** Press **2nd** **SET SYS** **ENTER** to return to DRO mode without changing setups.

Entering Numeric Information:

- Use minus key as required.
- If needed, clear incorrect entries by pressing **CLEAR**
- Last entry may be recalled by pressing **2nd** and axis key. Ex. **X**
- An axis may be de-selected by pressing the axis key again.
- More than one axis can be selected at a time for common numeric entry.

Enc RES Encoder Resolution

Can be entered by choosing a table value or with a numeric entry.

- Choosing the correct resolution - from the list of available settings:

Note: Current ACU-RITE encoders are metric scales.

- *Use the following table to choose the correct metric encoder setting from the internal list in the readout.*

Setting (mm)	Resolution label
.01	= 10um (.0005")
.005	= 5um (.0002")
.002	= 2um (.0001")
.001	= 1um (.00005")

- Press **ZERO** for current setting
- Press **ZERO** again to toggle through available settings
- **To make a numeric entry for ACU-RITE English scales or non-ACU-RITE encoders:**
- Press **CLEAR** to zero out display
- If needed, Press **2nd** **SET ABS** to set required measuring units. Enter numeric value.

NOTE: To clear an incorrect entry, Press **CLEAR**



LEC

Linear Error Compensation

Can be entered with a numeric entry or by using the automatic routine.

• **Setting LEC with a Numeric Entry:**

- Press **ZERO** for current setting.
- Enter PPM (Parts Per Million) with numeric keypad.
- Press **ENTER** to record setting.


Note: The sign is important; use the **-** key to change the sign of the compensation factor. Direct entry requires that the LEC factor be determined manually.

• **Setting LEC using Automatic Routine**

Requires either a manual or electronic Edge Finder Probe.


• **Manual Edgfinder, same side surfaces (ex: dial indicator)**

1. Install a measurement standard of known length on the table, aligned with table movement.
2. Install edgfinder securely in the tool holder or at another fixed reference position.
3. Press **ZERO** to display current setting.
4. Locate first edge of the standard,
Press **ZERO** again to zero the display.
5. Move to the opposite end of the standard. As the example illustrates, use a firm, flat surface to create a marker at the end of the standard. Touch the end marker with the same side of the edge finder used to touch off the first edge. The axis display will show the distance moved (usually this value will be slightly different from the length of the standard). Press **ENTER**.
6. At **tool dia** Press **0** **ENTER**
7. At **Std** Enter the length of the measuring standard,
Press **ENTER** - axis display will indicate calculated LEC factor in PPM.




• *Manual Indicator, opposite side surfaces*

1. Install a measurement standard of known length on the table, aligned with table movement.
2. Install edgefinder securely in the tool holder, or at another fixed reference position.
3. Press to display current setting.
4. Locate first edge of the standard,
Press again to zero the display.



5. Move to the opposite end of the standard.
Locate the second edge of the standard (usually the value will be slightly different from the length of the standard).



- Press
6. At Enter the diameter of the edgefinder probe tip, Press
 7. At Enter the length of the measuring standard,
Press - axis display will indicate calculated LEC factor in PPM.

NOTE: E4_Error

E4 error indicates the calculated LEC factor is outside acceptable range of -9999 to +9999. Typically the result of incorrect entry during automatic routine.

Press to re-start automatic routine at step 3.

- OR -

Press to return to manual entry.

Factor Multiplier Factor


Can be set either in Axis Parameter Setup or Quick Access Setup.
 Factory Default = 1.000000, or No Multiplier Factor

• **Setting Multiplier Factor**

- Press **ZERO** to view existing factor.
- Enter new value with numeric keypad.

Value > 1 ENLARGES features. Ex: setting scaling factor to 2 will double the size of the part as compared to the engineering drawing.

Value < 1 SHRINKS features. Ex: setting scaling factor to .5 will decrease the size of the part by 1/2, as compared to the engineering drawing.



NOTE: accommodating for material shrinkage. For a scaling factor that reflects 3% part shrinkage, determine the scaling factor as follows:

$$\begin{aligned}
 \text{Scaling Factor} &= 1/(1-\text{shrinkage factor}) \\
 &= 1/(100\% - 3\%) \\
 &= 1/(0.970) \\
 &= 1.0309
 \end{aligned}$$

Mirror Imaging: A scaling factor of -1.0 directly mirrors the dimensions entered. The scaling factor may be set to other negative values to both mirror and scale the features.

near 0 Near Zero Warning

Can be set either in Axis Parameter Setup or Quick Access Setup.
 Indicates that the tool is nearing zero. When the value of the axis display is within the near zero range set by the operator, the Near 0 annunciator (--> 0) on that axis will flash.



• **Quick Access Setup**

In Quick Access Setup Mode:

- Press **ZERO** for the current Near 0 value.
- Enter new range with numeric keypad.

Encoder Counting Direction

Sets positive and negative count direction.
 Factory Default = DIR 1

• Setting Count Direction

- Press **ZERO** for current setting.
- Press **ZERO** again to change direction.

Tool Offset Direction


This parameter indicates the edge of the tool that contacts the workpiece while the display value is increasing. Moving direction can be set for X and Y axes only.

Factory Default: **X** = Tool **6** • | **Y** = Tool **8** • |


• Setting Tool Offset Direction

- Press **ZERO** for current setting.
- Press **ZERO** again to toggle through available values:

X - increasing left-to-right = Tool **6** • |
 - increasing right-to-left = Tool • | **4**



Y - increasing outside-to-inside = Tool **8** • |
 - increasing inside-to-outside = Tool **2** • |



OPTION PARAMETERS

For RS-232, Multiple Scale Coupling (MSC) and Control Function Interface (CFI), refer to the Master Options manual.

- **Option Parameter Setting** - refer to Master Options Manual.

SLEEP

Sleep Mode Operation

Installed on all Master Readouts. Will turn displays "off" after 30 minutes of no activity (indicated by a moving dot advancing across the X-axis display). Displays are "awakened" by pressing any key or moving an encoder.

- **Setting**


- Press ^{OPTION}
- Press for current setting.
- Press again to toggle through available options:
 - 1 = Active
 - 0 = Not Active

MASTER READOUT OPERATIONS

DRO Operations

- Axis Display Settings**


Lighted annunciators on each axis indicate the current settings.




- Display Modes**


- Absolute and Incremental**

Absolute display shows the distance from your current position to Absolute Zero (current Datum/workpiece Zero).



Incremental display shows the distance from your current position to your last incremental zero.


- Press  to toggle through available choices.





- Distance-to-Go**

Dist-to-Go shows the distance from your current position to your next preset dimension (target position).

- Press  from any mode.



- Inch/Millimeter Measuring Units**

- Press   to change current setting.

- **Display Resolution**

Sets the display resolution as seen when the table is in motion. Resolution is available as High, Medium and Low. Refer to Appendix E in Section 5. Appendices, for a complete table of display options.

- Press **2nd** **DISP RES** **ABS INCR** to change the current setting.

Ex: A 10um (.0005") resolution linear encoder may be displayed as follows: .0005" / .001" / .002".

- **Zeroing Displays**

- **Absolute display**

New zero points for the absolute displays, or Datums, are created only with Datum Setting Procedures. (see Datum Operations section below)

- **Incremental display**

- Press **SET INCR** **ZERO** on the appropriate axis.

- **Distance-to-Go display**

- Press **DIST TO GO** **ZERO** on the appropriate axis.



Datum Operations

Datums are used to establish reference points for the workpiece. The Master-MP allows up to 10 Datum points, numbered 0 to 9. Datum 0 is normally set to coincide with workpiece zero, from which all features on the workpiece are referenced. When in the absolute display mode, display axes will show the tool distance from the current Datum. If no Datums have been set or selected, the readout defaults to Datum 0.

In the event of a Loss of Power, the Home Reference Point may be used to reestablish the position of Datum 0 without reindicating the workpiece (see Power Loss Restoration Features).

- **Setting Datum 0**

- Locate edge of your workpiece.
 - Press **⊖** **ZERO** for each axis.
 - If desired, shift Datum Zero to centerline of tool.
 - Press **⊖** **X** **RADIUS** **ENTER**





- **Multiple Datums**

Master-MP allows for the placement of up to 10 Datums, numbered 0 to 9. Datums may be set to a specific location from Datum 0, or can be referenced from one another. When changing Datums, the last Datum selected becomes the reference Datum. However, circular referencing (1 referenced to 2 and 2 referenced to 1) is not allowed, and Datum 0 cannot be referenced to another Datum. In the event of circular referencing, no offset distance entry will be allowed by the DRO.



- **Setting a Datum**


- **Setting Datums from the Current Location:**

- Move table to the position of the desired Datum.
 - Press 
 - Select a Datum number using the numeric keypad. Ex: Press **1**
 - Press **ZERO** for each axis. (Datum number is shown in the auxiliary display.)




- **Setting Datums from Print Dimensions:**

- Press  **0** **ENTER** to reference Datum 0.
 - Press 
 - Select a Datum number using numeric keypad. Ex: **2**
 - Press an axis key to select an axis. Ex. **X**
 - Enter the offset. Ex: **5**
 - Set other axes as needed.
 - Press **ENTER** to create the Datum and return to DRO operations.



Absolute displays will indicate the distance of the tool to the new Datum point.

- **Selecting a Datum**

- Press  **0** **ENTER** to select Datum 0 as the reference Datum.

Note: If the position of Datum 0 is changed, the position of all Datums change accordingly. All Datum offsets are maintained. The same is true for all Datums referenced from other Datums. For example: if Datum 3 is referenced from the position of Datum 2, and Datum 2 is moved 1/2" in the positive direction, Datum 3 will also move 1/2" in the positive direction.

Presetting Operations


Distance-to-Go can be preset to indicate the distance to a targeted location. Targeted locations can be referenced from the current position (an incremental preset) or from the current DATUM (an absolute preset).

• Entering Preset Mode

Press either or . Pushing either key will display the last preset values, and whether they were incremental or absolute, as shown by the display annunciators. Preset mode is indicated with a flashing "TARG" indicator.


• Setting Absolute Preset Referencing the Current Datum

- Press
- Enter numeric value. Ex: [1.00"] =
- Press
- Enter numeric value. Ex: [0.500"] =
- Press Display shows the Distance-to-Go from your current position to the target position.
- Move table until display shows zero.



• Setting Incremental Preset from Current Position (Distance-to-Go)

- Press
- Enter numeric value. Ex:
- Press Display will show the Distance to Go to the targeted position.
- Move table until display shows zero.



• Presetting Options


- To Re-use the previous preset entries for all axes, Press **DIST TO GO** in Preset Mode.
- To Select a DATUM prior to selecting an axis, Press **DATUM** **NUMERIC ENTRY** **ENTER**. Display will return to Preset Mode after selecting a DATUM.
- To Select another axis to preset, press the desired axis key. The previous axis is deselected.
- To Deselect an axis, press the axis key again. Display reverts to last preset value.

• Midpoint Presetting

Can be used to determine the midpoint of two features. Midpoint operations can be performed in the absolute or incremental mode.

• *Finding a Midpoint*

- Zero Absolute or Incremental display on first edge.
- Move to the second edge. Ex: 5.0000
- Press **2nd** **MID** **DIST TO GO**
- "MID" will flash on all axis; select axis. Ex: **X**
- "DIST" display shows distance to midpoint. Ex: 2.5000
- Move machine until display shows zero to reach midpoint position.



• Tool Offsetting

A tool catalog of up to 9 tools plus an edfinder can be stored. Catalog data includes tool number, diameter and length. Once tool settings are entered, displays will be modified to offset for tool diameters on X and Y and tool length offsets on Z.

• *Saving and Changing Tool Settings*

- Press **TOOL** Current tool number is indicated in the auxiliary display.
- Press tool number. Tool Diameter is displayed on Y axis.
- Press **X** or **Y** to change setting. Enter numeric value.
- Press **Z** twice to view current tool length. Press **Z** again to change setting. Enter value.
- Press **ENTER** to save changes and return to DRO mode, with that tool selected.

NOTE: To clear an incorrect entry, press **CLEAR**


• **Selecting a Tool**

- Press **TOOL** Current tool number is indicated in the auxiliary display.
- To Select an existing tool, press the desired number key.
- Press **ENTER** Tool number appears in auxiliary display.

- **Turn Tool Offsetting Off:** Select Tool 0 by pressing **TOOL** **0** **ENTER**

• **Setting Tool Edge Indicator**

- Press **TOOL**, **NUMERIC ENTRY** and **ENTER** to select desired tool.
- For X axis: press **4** to make the left side of the tool the cutting edge or **6** for the right side.
- For Y axis: press **8** to make the inside (further) side of the tool the cutting edge or **2** for the outside.
- Press **5** to establish the centerline of the tool for drilling holes.




• **Bolt Hole Patterns**

Circular hole patterns, or bolt hole circles, can be created with up to 99 holes. Hole patterns require parameter settings for the number of holes, pattern radius, the center location for the pattern, and the starting angle.

• **Entering a Bolt Hole Pattern**


- Press **HOLE PTRN**
 - Enter number of holes in pattern. Example: **4** **ENTER**
 - Enter radius of pattern. Example: **•** **5** **ENTER**
 - Enter center of hole pattern relative to the current DATUM.
- Example 2: **X** **2** **•** **5** **Y** **1** **•** **5** **ENTER**
- Enter starting angle (from positive X to positive Y)



- Example: **4** **5** **SET SYS** **ENTER**

- **Running a Bolt Hole Pattern**

- Press **HOLE PTRN** if not in Hole Pattern Mode.
- Press **DIST TO GO** Display shows location of first hole.
- Move table until display shows zero to reach first hole location.
- Press **NEXT** Display shows next hole location.
- Repeat the pattern by pressing **HOLE PTRN** **DIST TO GO**



Programming Operations

The Master-MP can hold programs up to 99 steps in length. Program steps consist of preset positions and hole patterns for up to 3 axes; and DATUM selection, tool selection and tool cutting edge indicator settings. DATUM and tool offset settings must be made separately (see Datum Operations). Programming operations are shown in the auxiliary display, which shows the "PROG" annunciator, a step number, and may indicate a DATUM, a tool, a hole pattern operation and indicates if a program is running.

Programs must be written in consecutive steps. While each step can have various characteristics (Ex: an entire bolt hole pattern of 99 holes can be ONE step), a program CANNOT have a blank step (a step without program information) between other steps.

- **Entering or Exiting Programming Mode:** Press **PROG**

- **Entering a New Program:**

- Press **PROG** to enter Programming Mode. Display shows the current step number. (Blank steps show a "PROG END" message.)
- Select a Step number (Programs may start at any step number.)
 - Either press **NEXT** until desired step is reached,
 - Or press **2nd** **NEXT** **NUMERIC ENTRY** **ENTER** to move to specific step.

• STEP 1: Entering an Absolute Preset

- If you are not there, go to the first step number.

Ex:


- Press to set the X dimension.

- Enter numeric value for X. Ex:

- Press to set the Y dimension.

- Enter numeric value for Y. Ex:

- Press



Your readout will display the preset dimension on the X and Y axes. The auxiliary display will read:
STEP 1, TOOL 1, DATUM 0, PROG.

- Press to go on to Step 2.

• STEP 2. Entering an Incremental Preset and Selecting a Tool

- Press to set the X dimension.

- Enter numeric value for X. Ex:

- Press to set the Y dimension.

- Enter numeric value for Y. Ex:


- Press

- Press to select tool from library.

- Press

- Select Tool Number. Ex:


- Press



- Press to go on to Step 3.

• **STEP 3. Entering a Bolt Hole Pattern**

- Press **HOLE PTRN**
- Prompt: "holes" Enter number of holes. Ex: **4** **ENTER**
- Prompt: "radius" Enter radius. Ex: **•** **5** **ENTER**
- Prompt: "center/center"
- Press **X** to select X axis
- Input pattern center dimension. Ex: **2** **•** **5**
- Press **Y** to select Y axis
- Input pattern center dimension. Ex: **1** **•** **5**
- Press **ENTER**
- Prompt: "angle" Enter the start angle of the first hole. Ex: **4** **5** **ENTER**




Your Readout will return to the "holes" prompt and display the current value. The auxiliary display shows: STEP 3, TOOL 1, DATUM 1, PROG.

■ Press **NEXT** to go on to

• **STEP 4. Setting an Absolute Preset from another DATUM**

- Press **SET ABS X** to set the X axis.
- Enter dimension for X. Ex: **-** **1**
- Press **Y** to set Y axis
- Enter dimension for Y. Ex: **•** **5**
- Press **ENTER**
- Press **DATUM** to select new DATUM
- Enter DATUM number. Ex: **2** **ENTER**



Your readout will display the preset dimension on the X and Y axes. The auxiliary display will read: STEP 4, TOOL 1, DATUM 2, PROG.

• Running a Program

- Press **PROG** if not in Program Mode.
- Press **2nd** **SELECT STEP** **NEXT**, number of first program step, **ENTER** to go to first step of program.
- Press **DIST TO GO**
- Press **NEXT** to go through program.

Note: While running a program, you can do any of the following operations:

- Jump to a specific step number by pressing the SELECT STEP key sequence.
- Select Tools
- Set X and Y axis tool edge indicators by pressing the tool edge keys.
- Enable CFI, it will be active until another step is chosen.

• Viewing or Editing a Program:

• *Review/Edit an existing program*

- Press **PROG** to enter program mode.
- Go to the beginning of the program
 - Either press **NEXT**
 - Or **2nd** **NEXT**, step number, **ENTER**
- Examine the tool, DATUM and tool edge indicator settings.
- For preset positions, examine the axis presets and the settings for absolute or incremental displays.
- For hole patterns, examine the pattern settings by pressing **HOLE PTRN**, then **ENTER** to toggle through settings.
- Existing step characteristics can be changed to desired settings, or steps can be added or deleted.

• *Inserting a program step*

- Press **2nd** **INSERT STEP** **HOLE PTRN** to insert a blank step at the current step number. (Current and all following steps will be pushed ahead one step number.)
- At "PROG End", enter your step information.

- **Deleting a program step**

- Press to delete the current step. (All following steps will be moved back one step number.)

- **Creating multiple programs**

- Repeat the steps to create a single program.
- Leave at least one BLANK STEP between programs to indicate end-of-program, and begin next program on the second blank step. Ex: Program 1 uses steps 1 through 4, Step 5 is blank and indicates the end of Program 1, Program 2 uses steps 6 through 11, Step 12 is blank, Program 3 begins on step 13.

- **Stopping the program at any point**

- Press to return to DRO mode.

- **Clearing the program memory**

- If needed, press to enter Program Mode.

- Press . All programs WILL BE CLEARED BY THIS KEY, NOT JUST THE CURRENT ONE.

Confirmation is required before programs are cleared. The X and Y axis will display "YES" and "NO" respectively. Press the axis key for the desired action.

Power Loss Restoration Features

- **Continu-Trac** - AC power is not lost, Press

- **Recall** - AC power is lost, no table movements have been made, Press

- **Home Reference Point (HRP) Find Routine**

The home reference point is a fixed reference mark along the machine table. It is found by sensing a reference signal on the encoder (the Fiducial Trigger Output signal, or FTO). FTOs are found every 8 inches (200 mm) on Mini-Scale and AR-5 Scales, and every 4 inches (100 mm) on MicroScales. Refer to your encoder manual for more information. Establishing a HRP creates the basis for referencing the position of Datum 0. After a loss of power, finding the HRP will allow you to return to your Datum 0 and restore all displays, DATUM locations and tool settings.

NOTE: The HRP should be established as one of the first operations when installing a Master Readout. This must be done prior to setting Datums. If Datums are established without first setting the HRP, the readout system cannot be returned to Datum 0 after power loss.

- **Setting HRP**

- Determine workpiece location.
- Find closest encoder reference mark.

- Press "REF" indicator will flash on all axes.

- Select an axis by pressing the axis key. Ex:

- Move table for the selected axis in a positive direction until you move across the closest FTO. This is indicated when the "REF" indicator disappears.

At this point, the incremental displays will be zeroed, and the previous offset for the absolute display for DATUM 0 will be restored. A Home Reference Point offset will remain effective as long as AC power is not lost, regardless of whether or not the readout displays are ON or OFF.

NOTE: For coupled encoders, see the Master Options Manual.

Using an Electronic EdgeFinder Probe

An edgfinder is used to locate workpiece edges and features, and can be used to measure workpiece features. The Electronic Edgefinder probe must be installed in the tool holder, with a cable connecting the Edgefinder to the Master-MP readout.

- **Electronic Edgefinder Probe Tool Settings**

- Press The tool annunciator in the auxiliary display will read "E".
- Prompt "DIA". Press any axis key and the numeric value of the diameter of the probe tip.

Ex:

- Press to save values and return to DRO Mode.


- **Zeroing at an Edge**

- **Setting Workpiece 0 with an Electronic Edgefinder Probe**





• Press

- Press an axis key, Ex: to select an axis to zero.

- Locate the edge of your workpiece with the Edgefinder. The display will zero out at the point of contact.





- **Setting Incremental Zero with an Electronic Edgefinder Probe**



- Press  to select Incremental displays.
- Press   to activate Edgefinder Probe. "Edgefinder" symbol will flash on all axes.
- Press the axis key of the axis to be zeroed. Ex:  The "edgefinder" symbol for this axis lights, but all other axes extinguish.
- Move the machine table to make contact with the workpiece. The Incremental display for this axis changes with table movement, and tool edge indicators change automatically to accommodate the direction of movement. When the Edgefinder contacts the workpiece, the display resets to zero, the "edgefinder" symbol light extinguishes and the tool edge indicator shows contact. (The indicator will no longer change as the table moves.) Further movements are shown on the axis display.


- **Finding Linear Error Compensation using an Electronic Edgefinder Probe**



1. Install a measurement standard of known length on the table, aligned with table movement.
2. Install Edgefinder securely in the tool holder.

3. Press  

4. Enter the Access Code Number found at the front of this manual.



5. Prompt  Press axis key you wish to change. Ex: 

6. Press axis key until you receive Prompt 





7. Press   to activate edge finder.


Locate first edge of the measuring standard, axis display zeros at point of contact.



8. Move to the opposite end of the standard.

Press  

Touch the end of the standard.

9. Prompt  Enter the diameter of the Edgefinder. Ex:   

10. Prompt 

Enter the length of the measuring standard Ex:  

Axis display will indicate calculated LEC factor in PPM.

Section 4. Appendices

Appendix A. Troubleshooting

This appendix covers some problems encountered with readout systems. Simple troubleshooting procedures are listed to assist service personnel with determining the extent of problems. If contacting your ACU-RITE Distributor, OEM/OEI, or the ACU-RITE Sales and Service Center for assistance, the service technician will need to know the results of these procedures.

- **No operation**

If the Master readout display will not operate, check the following conditions:

- **Check outlet** If the Master readout cannot be turned on, confirm that line voltage is present at the outlet.
- **Check power at cord** Remove the power cord at the electrical input module on the back of the Master readout. Determine if line voltage is present at this end of the cord.
- **Check fuse** With the power cord removed, use a thin straight-blade screwdriver to remove the cover of the electrical input module. Slide out the fuse holder and check the fuse. If necessary, replace it.



CAUTION

Replace fuses only with the specified type. Using incorrect fuses can present a safety hazard. The Master readout may also be permanently damaged.

Use a 1.0A, 250V, 3AG, slow-blow style fuse (1-1/4" x 1/4" dia.) for 100/120VAC operation; or a 0.5A, 250V, 3AG, slow-blow fuse for 220/240VAC operation. Replace the fuse in the fuse holder, and slide it back into the input module. Replace the input module cover by snapping it back into place, and reconnect the power cord.

- **Internal testing**

Several internal tests may be run to assure that the Master readout is functioning properly. Tests are available for the internal memory, the keypad, and the display. In addition, the testing procedure reports the version of the software programs built into the Master readout.

- **Begin the internal testing** from the OFF state by holding down the  key while pressing the  key. The software version is shown in the X-axis display.

- **Begin the memory test** by pressing the **X** key. After a short testing period, results are indicated in the X-axis display, as either "PASS" or "FAIL".
- **Begin keypad testing** by pressing the **X** key. Press each key (except the **X** key) in turn to verify that it is functioning properly. The X-axis display reports each key press by incrementing one digit starting with 0 and increasing to 9, then repeating.
- **Terminate keypad testing** and begin the display test by pressing the **X** key. All indicators in all displays are lit (including the auxiliary display for Master-MP and -TP readouts). Visually check each portion of each display to assure that they are functioning properly.
- **Return to the software version display** by pressing the **X** key. Repeat the tests as required.
- **Terminate the testing** at any time by pressing the **ON/OFF** key. The Master readout returns to the OFF state.
- **Resetting factory defaults**
Master readouts can be reset to the factory defaults to allow more in-depth troubleshooting or to install the readout on another machine.

IMPORTANT

Resetting the Master readout to factory defaults will clear all current settings. This includes the current position, ongoing operations, operator settings, and all parameters.

- **Reset the Master readout** by turning the displays OFF with the **ON/OFF** key. Hold down the **X**, **INMM SET ABS**, **3** and **●** keys simultaneously. The X-axis display momentarily shows a "CLR MEM" message, confirming the reset.
- **Error reports**
The Master readout includes built-in test and error-checking circuitry. This circuitry identifies errors that occur, and reports the problem to the operator.

System errors are reported to the operator with flashing error codes on the X-axis display, while axis errors are reported by flashing error codes in individual axis displays. Errors that are reported include loss of power, "E1"; counting (encoder signal miscount) errors, "E2"; display overflow (measurements too large to be displayed), "E4"; power-on memory error "E5"; programming error, "E6"; and memory test failure, "FAIL". Refer to Master Readout Operations for further details on resetting measurements to continue with machining operations following an error.

- **Loss of power** is indicated by a flashing "E1" error code in the X-axis display; all other displays are blank. Loss of power means that power to the Master readout has been interrupted. Since power to the encoders has also been interrupted, measuring information may no longer be accurate. Press the key to clear the error message. All display measurements are zeroed.
- **Counting errors** are indicated by a flashing "E2" error code in an axis display. Counting errors result from distorted electrical signals from an axis' encoder. These signals can be a result of an encoder malfunction, alignment or mounting problems, or electrical interference. Press the key to clear the error message. The axis display (for both absolute and incremental measurements) is zeroed.
- **Display overflow errors** are indicated by a flashing "E4" error code in an axis display. A numeric overflow occurs when the intended measurement is too large for the eight-digit display. Clear the error by returning the machine table into an area where measurements can again be displayed, selecting a lower display resolution, setting a new target preset, or zeroing the display with the key.

This error may also occur when using the automatic compensation routine while setting the LEC parameter. An error indicates that the calculated compensation factor was outside the acceptable range of -9999 to +9999, and usually is the result of incorrectly entering data. Clear the error and return to the beginning of the automatic error compensation routine by pressing the key.

- **Power-on memory errors** are indicated by a flashing "E5" error message in the X-axis display when the Master readout is turned on following a loss-of-power. An "E5" error denotes a serious internal failure, and indicates that some of the working settings are no longer valid. Working settings include current operating settings such as inches or millimeters; as well as programs, DATUMs, tool settings, current position information, and setup parameters.

Although all working settings can be checked and reset as required, they will likely be lost again when the power is interrupted. The Master readout should be serviced as soon as possible. Contact your ACU-RITE Distributor, OEM/OEI, or the ACU-RITE Sales and Service Center at (800) 344-2311.

Check all working settings before proceeding, and reset as required. Once reset, settings will be maintained until power to the Master readout is interrupted.

- **Program errors** are indicated by a flashing "E6" error code in the auxiliary display (Master-MP and -TP only). Error "E6" flags two related programming errors, either of which would result in a program or programs longer than 99 steps.

An "E6" error can occur when attempting to insert another step into a long program. With the INSERT STEP feature, all following program steps are pushed ahead by one step. The 99th step would be pushed ahead to become the 100th step, causing the error.

An "E6" error can also occur if the key is pressed when the current step is step 99. Since step 99 is the last available program step, attempting to move to the next step results in an error.

Press the key to clear the error and return to the current program step.

- **Memory failures** are indicated by a flashing "FAIL" error message in the X-axis display. A memory test failure indicates a serious malfunction with the Master readout.

CAUTION

The Master readout cannot be relied on for correct operation if a "Fail" message is shown during this test. The Master readout should be serviced immediately. Contact your ACU-RITE Distributor, OEM/OEI, or the ACU-RITE Sales and Service Center at (800) 344-2311.

The error message can be cleared with the key, and further testing or operations can be resumed.

Appendix B. Master Readout Specifications

Table 4-1. Master Readout Specifications

Characteristic	Specification
Operating conditions	0 to 40°C (32 to 104° F) 25 to 85% relative humidity (non-condensing)
Storage conditions	-40 to 60°C (-40 to 140° F) 25 to 95% relative humidity (non-condensing)
Input requirements	
Voltage:	100/120/220/240VAC (+/- 20%), single phase
Frequency:	50-60 Hz
Current:	0.75 A maximum
Fuse	110/120VAC operation: 1.0A, 250V, 3AG, Slo-blo 220/240VAC operation: 0.5A,
Electronics	Microprocessor-based circuitry
Number of axes	1, 2, or 3
Display	8-digit vacuum fluorescent display. MP and TP models also include a 4-digit display
Display resolution	Operator configurable. Refer to Table 4-6
Encoder resolution	10um, 5um, 2um, 1um 0.0005", 0.00025", 0.0001" Manual entry
Encoder input characteristics	Position signals: channel A & B TTL square wave signal in quadrature (90° nominal phase relationship). Maximum input rate: 50 KHz Reference signals: TTL square wave Fiducial Trigger Output signal (when provided)
Size	12.5" W x 6.0" D x 8.7" H
Weight	Approximately 15 lbs. (basic unit; options add additional weight)
Mounting	Bottom: four #8-32 threaded inserts Sides: two 1/4-20 threaded inserts (for ACU-RITE yoke mounts)
Recognition/ approval	UL, CSA pending
FCC compliance	Class A

Appendix C. Encoder Requirements

Table 4-2. Master encoder receptacle pin-out

Pin	Signal
A	Channel A square wave counting signal
B	Channel B square wave counting signal in quadrature (90° nominal phase relationship) with channel A signal
C	Vcc, +5.1 +/-0.1 VDC @ 140 mA (supplied by Master readout)
D	Common (power supply and signal return)
E	Shield, reading head casting ground
F	Fiducial Trigger Output (FTO) signal

If installing a non- ACU-RITE encoder, a connector kit may be obtained to adapt the encoder cable for use with the Master readout. Contact your ACU-RITE Distributor or OEM/OEI, or the ACU-RITE Sales and Service Center at (800) 344-2311, and order part number 382214-000.




Figure 4-1. Required encoder connector

Table 4-3. Master encoder receptacle pin-out

Characteristic	Requirement
Output signals Incremental	Two square-wave signals, channels A and B, in quadrature (90° nominal phase relationship)
FTO	One square-wave signal
Signal levels	Low: 0 to 0.8 VDC High: 3.5 to 5.1 VDC
Maximum current draw	140 mA
Minimum A to B channel edge separation	5 us




Figure 4-2. Typical encoder waveforms

Appendix D. Accessory Connectors and Output Specifications

All Master readouts are equipped with receptacles for the ACU-RITE VISION/Master Edgefinder Probe and ACU-RITE Master Foot Switch accessories

- **EdgeFinder**

The EDGEFINDER receptacle is provided for use with the ACU-RITE VISION/Master Edge Finder Probe accessory. The accessory is equipped with a cable that provides a mating connector.

Other manufacturer's edge finder probes may be used, if they perform the same functions as the ACU-RITE unit, and can be provided with a comparable connector. The connector from the edge finder must be a two-conductor, 1/8" (3.5mm) Mini-size Phone plug, such as Radio Shack part number 274-288. The ball or contact edge must be electrically isolated from the tool holder and the machine base. The conductor from the edge finder must be wired to the central contact on the plug, and the other conductor from the workpiece or machine base must be wired to the side contact on the plug.

- **Remote Zero**

The REMOTE ZERO receptacle is provided for use with the ACU-RITE Master Foot Switch Assembly accessory. The Foot Switch can be used in place of the ZERO key to zero a selected Master axis display.

Prior to installing the accessory, the connector supplied with the Foot Switch must be installed on the cable and wired to zero the desired axis. Refer to Table 4-5. for wiring information. For example, if the Foot Switch is to be used to zero the X-axis display, connect one wire on the Foot Switch cable assembly to pin 5, and the other wire to pin 1, 2, or 7.

Table 4-5. Remote zero receptacle pin-out

Pin	Signal
1	Ground
2	Ground
3	N.C.
4	Remote zero, Y- (Z1-) axis
5	Remote zero, X-axis
6	Remote zero, Z- (Z2-) axis
7	Ground
8	N.C.

Other switch arrangements may be used, if they perform the same functions as the ACU-RITE Foot Switch Assembly. Up to three switches may be provided for this assembly, one for each axis that is to be zeroed remotely. Each external switch must be a normally-open, momentary-closed, SPST switch. One side of each switch must be wired to one of the remote axis-zeroing connector pins (4, 5, or 6), and the other side wired to one of the ground pins (1, 2, or 7). The connector from the switch(es) must be an eight-conductor DIN plug, such as Switch Craft part #15BL7M.

Appendix E. Measurement displays

- **Display increments with standard encoder resolution selections**

The DISP RES feature allows setting display resolution to high resolution, medium, or low resolution. Table 4-6. shows the least-significant digit and number of decimal digits displayed, with each selection of encoder resolution provided by the Master readout. The table shows these characteristics for all combinations of inches vs. millimeter and radius vs. diameter (Master-G only) settings.

Table 4-6. Master display increments with various settings

Encoder Resolution	INCH, RAD			INCH, DIA			MM, RAD			MM, DIA		
	High	Medium	Low	High	Medium	Low	High	Medium	Low	High	Medium	Low
10 μ m	0.0005	0.001	0.002	0.001	0.002	0.005	0.01	0.02	0.05	0.02	0.05	0.1
5 μ m	0.0002	0.0005	0.001	0.0005	0.001	0.002	0.005	0.01	0.02	0.01	0.02	0.05
2 μ m	0.0001	0.0002	0.0005	0.0002	0.0005	0.001	0.002	0.005	0.01	0.005	0.01	0.02
1 μ m	0.0005	0.0001	0.0002	0.0001	0.0002	0.0005	0.001	0.002	0.005	0.002	0.005	0.01
0.0005"	0.0005	0.001	0.002	0.001	0.002	0.005	0.02	0.05	0.1	0.05	0.1	0.2
0.00025"	0.0005	0.0005	0.001	0.0005	0.001	0.002	0.01	0.02	0.05	0.02	0.05	0.1
0.0001"	0.0001	0.0002	0.0005	0.0002	0.0005	0.001	0.002	0.005	0.01	0.005	0.01	0.02

1. The table illustrates Master display increments with various combinations of INCH/MM and RAD/DIA key settings.
2. The display increments corresponding to a diameter setting are valid only if diameter displays are enabled on that axis.

Appendix H. Warranty

- **FCC compliance statement**

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions in this manual, may cause interference to radio communications. It has been tested and found to comply with the limits in effect at the time of manufacture for a Class A computing device pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

- **The ACU-RITE warranty**

ACU-RITE products and accessories are warranted against defects in material and workmanship for a period of three years from the date of purchase. ACU-RITE will, at its option and expense, repair or replace any part of the ACU-RITE product which fails to meet this warranty. This warranty covers both materials and factory service labor. In addition, ACU-RITE Distributors and OEM/OEI service representatives will provide service labor (field service) for a one-year period at no charge. Notice of the claimed defect must be received by ACU-RITE within the warranty period.

This warranty applies only to products and accessories installed and operated in accordance with this reference manual. ACU-RITE shall have no obligation, with respect to any defect or other condition caused in whole or in part by the customer's incorrect use, improper maintenance, modification of the equipment, or by the repair or maintenance of the product by any person except persons deemed by ACU-RITE to be qualified.

Responsibility for loss in operation performance due to environmental condition, such as humidity, dust, corrosive chemicals, depositions of oil or other foreign matter, spillage, or other conditions beyond ACU-RITE's control cannot be accepted by ACU-RITE.

There are no other warranties expressed or implied, and ACU-RITE INCORPORATED shall not be liable under any circumstances for consequential damages.

- 30-day Red Carpet Warranty Service

IMPORTANT

Keep the box and packing materials.

Your ACU-RITE Master readout is covered by a 30-day Red Carpet Warranty Service. If in the first 30 days this product fails for any reason, repack it in the original packing materials and contact your ACU-RITE Distributor, OEM/OEI, or the ACU-RITE Sales and Service Center at (800) 344-2311 for return instructions.

For future ordering information or warranty service, record the following information:

Master readout serial number (located on bottom of unit): _____

Software version (from internal tests): _____

Encoder catalog and serial numbers:

X-axis: _____

Y- (Z₁-) axis: _____

Z- (Z₂-) axis: _____

Date of purchase: _____

Distributor: _____

Address: _____

Telephone: _____



**ACU-RITE Readout Systems
are manufactured in the USA**



ACU-RITE®

ONE PRECISION WAY
MASON INDUSTRIAL PARK
JAMESTOWN, NEW YORK 14701
(800) 344-2311



PRINTED IN U.S.A.